

Uniden UHF, Marin Radios & Scanners Resetting Procedure

Updated on 04/11/2016

UHF Radios:

Model No: UH011

Turn the unit off, Press and hold “TSQ” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then turn on

Model No: UH012SX

Turn the unit off, Press and hold “INST” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then turn on.

Model No: UH013SX

Turn the unit off, Press and hold “INST (SET/SKIP)” & “SQ” buttons together at the same time and turn the power back on. After 15 seconds turn power back off, then turn on.

Model No: UH015SX

Turn the unit off, Press and hold “DCS/CTCSS” & “POL(MEM)” buttons together at the same time and turn the power back on. After 15 seconds turn power back off, then turn on.

Model No: UH035

Turn the unit off, Press and hold “DUP” & “MON” buttons together at the same time and turn the power back on. After 15 seconds turn power back off, then turn on

Model No: UH036/UH035-2

Turn the unit off, Press and hold “[channel▲] and [vol▲]” buttons together at the same time and turn the power back on. After 15 seconds turn power back off, then turn on.

Model No: UH037

Turn the unit off, Press and hold “DUP” & “MON” buttons together at the same time and turn the power back on. After 15 seconds turn power back off, then turn on

Model No: UH037SX-NB

Turn the unit off, Press and hold “[channel▲] and [vol ▲]” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH038SX/UH038SX-NB

Turn the unit off, Press and hold “SCAN” & “MON” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH039

Turn the unit off, Press and hold “[mon] and [vol▲]” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then turn on

Model No: UH040XR

Turn the unit off, Press and hold “SCAN” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH041

Turn the unit off, Press and hold “[mon] and [vol▲]” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH042XR

Turn the unit off, Press and hold “SCAN” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH043SX/UH043SX-NB

Turn the unit off, Press and hold “SCAN” & “MON” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH044XR

Turn the unit off, Press and hold “SCAN” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH044SX

Turn the unit off, Press and hold “SCAN” & “CALL” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH047

Turn the unit off, Press and hold “SCAN” & “MON” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH049SX

Turn the unit off, Press and hold “SCAN” & “MEM” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH050XR

Turn the unit off, Press and hold “SCAN” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH052

Turn the unit off, Press and hold “SCAN” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH054

Turn the unit off, Press and hold “SCAN” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH060

Turn the unit off, Press and hold “SCAN” & “TXP/CTCSS” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH064/UH064SX-NB

Turn the unit off, Press and hold “SCAN” & “MON” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH065SX

Turn the unit off, Press and hold “SCAN” & “MEM” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH073SX

Turn the unit off, Press and hold “OS/GS” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH074SX

Turn the unit off, Press and hold “Mem” & “OS/GS” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH075

Turn the unit off, Press and hold “Mem” & “OS/GS” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH076SX/UH076SX-NB /UH076DLX

Turn the unit off, Press and hold “Mem” & “OS/GS” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH077

Turn the unit off, Press and hold “SCAN” & “DUP” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH078SX/UH078SX-NB

turn the unit off, Press and hold “Mem” & “Menu” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH088SX

Turn the unit off, Press and hold “TSQ” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH089SX

Turn the unit off, Press and hold “OS/GS” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH089NB/UH5040

Turn the unit off, Press and hold “DIM” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH090

Turn the unit off, Press and hold “FM/AM(DUAL)” & “SCAN(OS/GS)” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH095SX

Turn the unit off, Press and hold MON” & “AM/FM(DUAL)” buttons together at the same time and turn the power back on .After 15 seconds turn power back off then on

Model No: UH100

Turn the unit off, Press and hold “SCAN” & “SCRAMBLE(TSQ)” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH305SX-2NB

Turn the unit off, Press and hold “[channel▲] and [vol ▲]” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH400SX/UH500SX/UH5050

Turn the unit off, Press and hold “DCS/CTCSS” SCAN & “MEM” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH405SX-2NB

Turn the unit off, Press and hold “[channel▲] “ & “[vol▲]” & “[vol▼]” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH506SX-2NB/UH515DLX-2/UH510,

Selected Channel 21, Turn the unit off, Press and hold “[channel▼]” & “hi/lo” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH507SX-2NB

Selected Channel 21, Turn the unit off, Press and hold “[channel▼]” & “hi/lo” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH710SX/UH710SX-NB

Turn the unit off, Press and hold “MON/DUAL”& “MENU/ENT” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH720SX/UH720SX-NB

Turn the unit off, Press and hold “MON/DUAL”& “MENU/ENT” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH7700NB/UH5000/UH5000PNP

Turn the unit off, Press and hold “MENU”& “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH7740NB/UH5045

Turn the unit off, Press and hold ‘MEM’ & ‘DCS/CTCSS’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH7750NB/UH5050

Turn the unit off, Press and hold ‘MEN’ & ‘DCS/CTCSS’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH7760NB/UH5060

Turn the unit off, Press and hold ‘MENU’ & ‘SCAN’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH810S/UH820S

Turn the unit off, Press and hold ‘MENU’ & ‘Smart’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH820NB

Select channel 21, Turn the unit off, Press and hold ‘Call’ & ‘SCAN’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH835S/UH850S

Turn the unit off, Press and hold ‘MENU’ & ‘[▲]’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH8010NB/UH8010S

Turn the unit off, Press and hold ‘MENU’ & ‘SCAN’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH8020S

Turn the unit off, Press and hold ‘MENU’ & ‘SCAN’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH8050S/UH8055

- *Initialize to factory setting not including recorded audio.*

Turn the unit off, Press and hold ‘MENU’ & ‘REPALY’ buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

- *Reset All including recorded audio*

Turn the unit off, Press and hold ‘MENU’ & ‘Replay’ & ‘Police’ buttons together at the same

time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH8060NB/UH8060S/UH9000

Turn the unit off, Press and hold "MENU" & "SCAN" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH8070S/UH8080S

- *Initialize to factory setting not including recorded audio.*

Turn the unit off, Press and hold "MENU" & "REPALY" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

- *Reset All including recorded audio*

Turn the unit off, Press and hold "MENU" & "Replay" & "Police" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH8080NB

- *Initialize to factory setting not including recorded audio.*

Turn the unit off, Press and hold "MENU" & "REPALY" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

- *Reset All including recorded audio*

Turn the unit off, Press and hold "MENU" & "Replay" & "SQL" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH9060/UH9080

- *Initialize to factory setting not including recorded audio.*

Turn the unit off, Press and hold "MENU" & "REPALY" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

- *Reset All including recorded audio*

Turn the unit off, Press and hold "MENU" & "Replay" & "DCS/CTCSS" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UH950S

Turn the unit off, Press and hold "INST" and "[vol ▲]" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: PRO5050

Turn the unit off, Press and hold "DUL" & "MEM" buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: PRO630XL

Turn the unit off, Press and hold “ANL” & “MEM” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Marine Radios:**Model No: UM355VHF**

Turn the unit off, Press and hold “INST” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UM425VHF

Turn the unit off, Press and hold “MENU” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: UM455VHF

- Without MMSI

- 1 : Pressing and Holding [CLR] & [CALL] Keys, Power Turn-On (go to Test Mode)
- 2 : Press [ENT] Key at LCD TEST
- 3 : Press & Hold [16/9] Key then Memory will be cleared
- 4 : Power Off

Model No: UM423AM

Turn the unit off, Press and hold “DUAL/88” & “CALL/PA” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: Voyager

Turn the unit off, Press and hold “TRI” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: Atlantis 260

Turn the unit off, Press and hold “TRI” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: Atlantis 250

Turn the unit off, Press and hold “TRI” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: MHS050

Turn the unit off, Press and hold “VOL/▼” & “SCAN/MEM” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: MHS115

Turn the unit off, Press and hold “VOL/TX” Power & [INST] buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: MHS115UV

Turn the unit off, Press and hold “VOL/Lock” & [INST] buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: MHS127

Turn the unit off, Press and hold “VOL” & [INST] buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: HH955

Turn the unit off, Press and hold “MEM” & “SCAN” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model No: MHS115

Turn the unit off, Press and hold “VOL/TX power” & “INST” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Scanners

Model: EZI30XLT

Turn the unit off, Press and hold “No 2” & “Store” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model: UBC126AT, UBC396XLT, UBCT8, UBC330CR UBC340CRS,, UBC72XLT, UBC73XIT, UBCC92XLT, UBC93XLT, UBC996T, UB CD325P2

Turn the unit off, Press and hold “No 2”, “No 9” & “Hold” buttons together at the same time and turn the power back on. After 15 seconds turn power back off then on

Model: UBC355XLT


Turn the unit off, Press and hold “L/O” & “Program” buttons together at the same time and turn

the power back on. After 15 seconds turn power back off then on

Model: UBCD436-PT

1. To perform a factory reset, scroll down and select "Initialize Setting" and then confirm by pressing "E".
2. Turn the Scroll Control Knob to "Initialize Setting" and press the Knob.
3. Press Enter button ().

Model: UBCD536-PT

1. Press MENU then turn the Scroll Control Knob to "Settings" and press the Knob.
2. Turn the Scroll Control Knob to "Initialize Setting" and press the Knob.
3. Press Enter button ().

Please note: All memory will be deleted after Reset applied